

# Valk Standard & Tourer & Interstate

## Ultimate KING Bigboy rider backrest

### Installation instructions

#### Mounting hardware included

2 – bolts 6 mm x 20 mm w/washers

1 – hex key 4 mm

1. Remove both rider and passenger seats from the bike.
2. Place your new Ultimate passenger seat on the rear fender and line up the bolt holes.
3. Place the King backrest bracket on the front passenger seat bracket and line up the bolt holes.
4. Screw in the two 6mm bolts supplied through the backrest and passenger seat brackets into the fender. (Fig 1)
5. Tighten the two front bolts and the rear bolt securely to complete the installation of your passenger seat and rider backrest.
6. Install the King Bigboy seat on the bike. (Fig 2)



Fig 1



Fig 2

If you need help call us on 1-800-818 6868

Or email [des@ultimateseats.ca](mailto:des@ultimateseats.ca)