

Harley-Davidson® Softail® 2006 – 2007

155 mm tire

Not wide tire models

Ultimate seats Installation

Install kit

Phillips pan head bolts $\frac{1}{4}$ " x $\frac{1}{2}$ " long with lock washers = 3 pcs

Round head Allen bolts $\frac{1}{4}$ " x $\frac{3}{4}$ " long = 2 pcs

Hex nut threaded inserts for side mount = 2 pcs

#1. Remove original seats from your bike.

#2. Your new Ultimate seats install using the front seat side mount bolts and the passenger seat is bolted to the front seat and rear fender.

Side mount hex nuts = 2. If your stock rider seat is a rear fender mount, install one of the hex nut inserts on each side of the frame if they are not in your bike frame already.

#3. All the mounting brackets are already installed on your new seats.

#4. Connect our passenger seat to the rider seat with the 2 new round head allen bolts ($\frac{1}{4}$ " x $\frac{3}{4}$ "

#5. Use the 2 new supplied bolts to attach the rider seat to the bike frame, one on each side into the threaded inserts ($\frac{1}{4}$ " x $\frac{1}{2}$ " pan Phillips head)

#6. Use the other new bolt for the passenger seat rear bracket in the fender ($\frac{1}{4}$ " x $\frac{1}{2}$ " pan head.

Enjoy the ride again

Questions ??? call us on 1-800-818 6868 or email des@ultimateseats.ca

Web site – www.ultimateseats.ca