

Can-Am Spyder RS – all models

Ultimate seat Installation - one pc seat

Install Kit for passenger backrest

4 mm T handle Allen key

6 mm x 30 mm button head screw

Removal of Stock Seat

Follow your Spyder owner's manual to remove the seat

Install your new Ultimate seat

1. Remove the necessary mounting brackets from your stock seat base pan and install them onto your Ultimate seat base pan.
2. Remove the passenger seat sensor and reinstall it into your Ultimate base pan.
3. Follow your Spyder owner's manual to install the seat.
4. Note that the front locking pin on the pan is adjustable so it is the last thing to complete. Leave the lock nuts on the pin just loose enough so you can line up the latch hole and then tighten correctly.
5. If you have the Ultimate removable passenger backrest install it before you replace the rear plastic body panel. Use the supplied 4 mm Allen key to screw in the locking screw. Slide the backrest post into the seat receiving bracket and line up the threaded hole with the screw and tighten.

Enjoy the ride again on your Ultimate seats

Questions ??? call us on 1-800-818 6868

or email des@ultimateseats.ca

Web site – www.ultimateseats.ca