

Ultimate Seats

VALKYRIE ARMREST INSTALLATION

Before you start, place a thick cloth over the fender below the area you will be working on for protection if you drop the parts.

Remove the 3 nuts holding the passenger pad on the Sissy Bar and remove the pad.

Remove the 2 outside nuts and bolts from the clamp bracket.

Take the entire armrest and standing behind the Sissy Bar tilt the armrest so the clamp bracket can fit through the Sissy Bar.

Place the bracket just above or just below the 2 lower bolt pads, use these 2 pads to rest the mounting bolts against, this will also level the armrest.

Reinstall the 2 outside nuts and bolts in the clamp bracket.

Have your passenger sit on the bike and make the height adjustment up or down and tighten the clamp.

Reinstall the passenger pad, if you have the Ultimate pad use the 3 new longer bolts supplied.

When dismantling you must first flip up the armrest Do not use them to push yourself up They are not intended to be used in this manner. Please make sure your passenger is told this. Damage to the hinge will occur if they are used incorrectly.

Your new armrest has a quick release hinge pin so if you wish to remove the armrest and leave the mounting bracket attached to the backrest just slide out the hinge pin and remove the arms.

Questions ? call us on 1-800-818 6868 or email des@ultimateseats.ca
Web site www.ultimateseats.ca