

VTX 1300 – C

ULTIMATE SEATS INSTALLATION

Mounting hardware included;

- One spool washer
- Two nylon washers
- One M6 x 25mm stainless bolt
- One 4 mm hex key

1. Remove the bolt in the center of the fender (10 mm wrench or socket)
2. Install the Spool washer on the fender (existing threaded hole) using the supplied M6 bolt. Use one nylon washer between the Spool and the fender.
3. Install the ultimate rider seat using the 2 stock bolts on each side



4. Install the passenger seat by sliding the support bracket into the spool washer under the rider seat.



5. Use one nylon washer between the fender and the rear chrome seat bracket.
6. Replace the chrome acorn nut to secure the rear seat.

Questions ??? call us on 1-800-818 6868 or email des@ultimateseats.ca www.ultimateseats.ca