



## **THE ULTIMATE SEAT COMPANY LTD.**

### **Blinker Buddy**

#### **Device wiring for Rune**

**The main part of the device has already been installed in the seat at Ultimate Seats. You will notice a connector coming out from the device under the seat. This is where the power wire will attach after it has been connected to your bike.**

**Start by installing the power wire that came with the seat. The end with the connector is the top end and should be located above the battery with about 12" of extra wire. Snake the wire down to behind the left "side" cover. Use the zip ties to hold the wire so it doesn't hang anywhere. Be sure the wire doesn't get pinched or left in an area where it may get damaged or melted. You will need to leave some slack at the top, so the seat removal will be easily accomplished in the future.**

**Remove the left chrome side cover. The wiring loom is up under the frame behind this cover. You will find a square connector; look for the turn signal wires coming out of the connector, there is one light Blue and one Orange.**

**Splice into these and connect the device wires, one black and one red, polarity is not important, the wires can be connected either way.**

**Plug the connectors together under the seat and loop the wire in a circle while positioning the seat carefully and locking it down. Be sure not to pinch the wire under the seat.**

**Get on the bike, start it up and turn on the signal switch. You will feel the device buzzing on and off, in sync with the signal lights. Reinstall the side cover.**

**If it ever fails to operate, but your signals are still working, check the device wire for damage resulting in a break in the wire. If the fuse for the signals blows, check the wire for damage resulting in a "short circuit".**

**Relax though...  
You will never leave your blinkers on again.**