

ULTIMATE SEATS

Removable Rider Backrest

If you have the Ultimate removable rider backrest you install it by lifting the Velcro flap on the seat and sliding the backrest post into the backrest bracket inside the seat.

You will see a groove in the backrest post, there is a spring-loaded plunger inside the seat bracket that clicks into the groove.

When you fold the backrest forward and down for easy mount and dismount make sure the Velcro tab is folded forward and down so the adjustment bolt rests on it and not directly on the seat.

With the backrest in the upright riding position you can infinitely adjust the forward and back position by turning the adjustment bolt.

The backrest hinge should be adjusted so it tilts freely to the angle of your back but firm enough to stay in the set position.

Questions ? call us on 1-800-818 6868 or email des@ultimateseats.ca

Web site www.ultimateseats.ca